

Getting Started With

# OPTURA<sup>SM</sup>

*LocalTV*



# Table of Contents

- Available Local Channels..... 3
  - Henry and Knox County ..... 3
  - Fulton, Peoria and Stark County ..... 3
- Customer Steps: Already Have an Existing Roku Account ..... 4
  - Step 1: Installing The OPTURA LocalTV App ..... 4
  - Step 2: Enjoy ..... 4
  - Step 3: Channel Functionality and Tips..... 4
- Customer Steps: Setting Up Your Roku Device And Account ..... 5
  - Step 1: Connect To Your TV ..... 5
  - Step 2: Power Up Key Components..... 5
  - Step 3: Connect To Your Network ..... 5
  - Step 4: Complete Guided Setup ..... 6
  - Step 5: Installing The OPTURA LocalTV App ..... 6
  - Step 6: Enjoy ..... 6
  - Step 7: Channel Functionality and Tips..... 7

## Important Note:

Please be advised that your OPTURA Local TV service is available to Mid Century high-speed Internet customers only and requires the following:

- **Internet speeds of 3 Mbps for HD, 1Mbps for SD**
- **Requires a Roku player**
- **Wireless or Wired Router**

*\*If you move your Roku player to another Internet connection outside of Mid Century your OPTURA Local TV Service will not work.*



## Available Local Channels

### Henry and Knox County

- ABC-WQAD TV8
- ANTENNA TV-WQAD DT2
- CBS-WHBF TV4
- COZI
- CW-KGCW TV26
- FOX-KLJB TV18
- METV-KGCW DT2
- MNTV-WQAD DT3
- NBC-KWQC TV6
- PBS-KQIN
- PBS-WQPT TV24
- PBS - IPTV Learns
- PBS IPTV World
- WQPT-MHz World

### Fulton, Peoria and Stark County

- ABC-WHOI TV19
- BOUNCE-WMBD D2
- CBS-WMBD TV31
- CometTV - WHOI
- CW - WHOI
- FOX - WYZZ TV43
- MNTV-WAOE TV59
- NBC-WEEK TV25
- PBS-WTVP TV47
- WTVP - World
- WTVP - Create

### **Plus You Receive:**

- Quick access to Netflix, Amazon Instant Video and Hulu Plus
- Over 1,000+ channels of free, subscription-based and pay-per-use streaming on-demand music, video and game options.

## **Customer Steps: Already Have an Existing Roku Account**

*NOTE: You must first sign up for OPTURA LocalTV and register your Roku serial number with Mid Century before installing the app. OPTURA LocalTV is only authenticated for use within the Mid Century Internet Network.*

### **Step 1: Installing The OPTURA LocalTV App**

- On your computer, go to <https://owner.Roku.com/add/OpturaLocalTV>
- You will be prompted to log into your Roku account
- Click “Yes Add Channel”, it should show immediately. If not, you can refresh your channels on your Roku home screen by selecting: Settings > System update or settings > Player info and checking for an update.

### **Step 2: Enjoy**

- To watch your live OPTURA LocalTV, simply select the OPTURA LocalTV channel from the Roku Home screen!

### **Step 3: Channel Functionality and Tips**

- Change channels by using the up and down arrows on your Roku remote. The channel listing will appear momentarily in the upper left-hand corner of the screen.
- Press the \* button on the Roku remote to access the channel list. You can then use the up and down arrows to scroll through the list. Use “ok” or “select” buttons to go to desired channel.
- The ← will take you back to the previous screen.
- There is a Roku remote control app available for your

iPad or iPhone in the App Store, or for your Android device on Google Play

## **Customer Steps: Setting Up Your Roku Device And Account**

### **Step 1: Connect To Your TV**

- Simply connect one end of the HDMI cable to the HDMI port on Roku player, and the other end to an available HDMI input on your TV. Be sure to make note of the TV input used.

### **Step 2: Power Up Key Components**

- Install the batteries on the Roku remote (Note: the front LED lights on the remote will flash indicating it is ready to pair to your Roku player).
- Power up the Roku player.
- Turn on your TV and select the correct TV input.
- During the start-up process, the Roku remote will automatically pair to your Roku player (the front LEDs will stop flashing).

### **Step 3: Connect To Your Network**

- For best results, connect your Roku player via the Ethernet port (Roku 3 only).
- Wireless setup, place the Roku player within range of your wireless network (closer is better). Also don't place your Roku player in any type of enclosed cabinet; it could interfere with the wireless signal.

## Step 4: Complete Guided Setup

- During the setup you will be prompted to create a Roku account online. Your Roku player will generate a unique code that links your player to your new account. Although Roku accounts are free, it does require a valid credit card to create your account (this is Roku policy, an independent of OPTURA LocalTV). Roku will only charge your credit card if you authorize purchases of paid channels, games or other content from the Roku Channel store.
- Your Roku player will let you know if software updates are available and will restart after the update is complete.
- Now, link your Roku player from your Internet browser. A link code should be displayed on the TV screen after restart. Follow the instructions to link your Roku player to the Roku account.

## Step 5: Installing The OPTURA LocalTV App

- On your computer, go to <https://owner.Roku.com/add/OpturaLocalTV>
- You will be prompted to log into your Roku account
- Click “Yes Add Channel”, it should show immediately. If not, you can refresh your channels on your Roku home screen by selecting: Settings > System update or settings > Player info and checking for an update.

## Step 6: Enjoy

- To watch your live OPTURA LocalTV, simply select the OPTURA LocalTV channel from the Roku Home screen!

## Step 7: Channel Functionality and Tips

- Change channels by using the up and down arrows on your Roku remote. The channel listing will appear momentarily in the upper left-hand corner of the screen.
- Press the \* button on the Roku remote to access the channel list. You can then use the up and down arrows to scroll through the list. Use “ok” or “select” buttons to go to desired channel.
- The ← will take you back to the previous screen.
- There is a Roku remote control app available for your iPad or iPhone in the App Store, or for your Android device on Google Play.



285 Mid Century Lane | PO Box 380 | Fairview, IL 61432

309.778.8611 | Fax: 309.783.3297

[www.midcentury.com](http://www.midcentury.com)